



Model XPH14T/Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
1	857W05-7	XPH14 NAME PLATE	1	
2	266130-9	TAPPING SCREW BIND PT 3X16	7	PC.
3	191M80-6	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCK NUT M4-7	2	PC.
	D10	INC. 20,21		
4	232220-0	LEAF SPRING	2	PC.
5	127494-5	SPEED CHANGE LEVER ASSEMBLY	1	PC.
	C10 233438-6	COMPRESSION SPRING 4	2	PC.
6	251468-5	FLAT HEAD SCREW M6X22	1	PC.
7	763252-1	KEYLESS DRILL CHUCK 13	1	PC.
8	127698-9	GEAR ASSEMBLY	1	
9	266326-2	TAPPING SCREW 4X18	4	PC.
10	619656-4	ROTOR	1	
11	629A33-8	STATOR COMPLETE	1	
12	413199-6	REAR COVER	1	
13	266130-9	TAPPING SCREW BIND PT 3X16	2	PC.
14	419041-9	F/R CHANGE LEVER	1	PC.
15	651443-5	SWITCH C3JR-4B	1	PC.
16	643874-2	TERMINAL	1	PC.
17	857W06-5	XPH14 SERIAL NO. LABEL	1	
18	424517-3	CUSHION	1	PC.
19	620549-0	LED CIRCUIT	1	PC.
20	191M80-6	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCK NUT M4-7	2	PC.
	D10	D10. 3,21		
21	8012S6-4	CAUTION LABEL	1	
A01	122576-8	STOPPER POLE ASS'Y	1	PC.
A02	127701-6	GRIP ASSEMBLY	1	
	C10 140U91-6	POLE COMPLETE	1	
	C20 140X19-2	ARM R COMPLETE	1	
	C30 265785-7	THUMB SCREW M5X10	1	PC.
	C40 266886-4	HEX. BOLT M8X65	1	PC.
	C50 312A63-3	ARM L	1	
	C60 931202-6	HEX. NUT M5	1	PC.
	C70 962055-2	RETAINING RING (INT) R-15	1	PC.
A03	251314-2	SCREW M4X12	1	PC.
A04	346449-3	HOOK	1	PC.
A05	450128-8	BATTERY COVER	2	PC. (XPH14T)
A06	***DC18RC	DC18RC FAST CHARGER	1	PC.
	D10	COMPO-PARTS		
A07	BL1850B	BATTERY BL1850B SET (197283-2)	2	PC. (XPH14T)
A08	831253-8	TOTE BAG	1	PC. (XPH14T)