SERVICE PARTS LIST

Milwaukee

EXAMPLE:

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS 12 Volt 3/8" Square Drive Impact Wrench

REVISED BULLETIN 54-26-2460

Mar. 2013 WIRING INSTRUCTION

DATE


CATALOG NO.

2451-20

STARTING SERIAL NO

C08B

SEE PAGE THREE




NOTE: Gear Assembly (28) must be attached to the Motor Assembly (7) prior to installing in Gearcase Assembly (36).

Component Parts (Small #)

Are Included When Ordering

Service replacement Gear Assembly (28) comes with a motor mount plate that must be removed and discarded when servicing. A Motor Mount Plate (10) already exists on the Matar Assembly (7). the Motor Assembly (7).






FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	31-50-2402	Handle Set	(1)
2		Left Handle Half	(1)
3		Right Handle Half	(1)
4	45-24-0105	Fwd./Rev. Button	(1)
★ 5	23-66-1106	Electronics Module Assembly	(1)
6	06-82-2385	M2.6 x 14 T-9 Screw	(5)
7	23-30-0090	Motor Service Assembly	(1)
8		Motor	(1)
9		Pinion	(1)
10		Motor Mount	(1)
11		Washer	(2)
12		M3 x 6 Screw	(2)
13	06-65-0075	Pin	(2)
14		Washer	(1)
15		Ring Gear	(1)
16	42-70-0055	Clip	(1)
17		Planet Gear Set	(8)
18		Sun Gear	(1)
19	10-20-0790	Warning Label	(1)
20		Carriage	(1)
21		Rear Housing	(1)
22		Ball Bearing	(1)
23		Cam Shaft	(1)
24		3/16" Dia. Steel Ball	(2)
25		Compression Spring	(1)
26		Washer	(1)
27		3.0mm Dia. Steel Ball	(29)
28	14-29-0190	Gear Assembly	(1)

F	FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
	30		Hog Ring	
			(See page two)	(1)
	31	45-88-0455	Washer	(1)
	32	06-65-0085	Pin	(2)
	36	14-30-0005	Gearcase Assembly with Bushing	(1)
	37	06-81-0005	M3.5 x 24 Screw	(4)
	38		Anvil Assembly	. ,
			(See page two)	(1)
	39		Rubber Ring	
			(See page two)	(1)
	44		LED Label	(1)
	45		Hammer	(1)
	46	12-20-2452	Service Nameplate	(1)
	47		Fuel Gauge LED Assembly	(1)
	48	42-55-2450	Carrying Case, Optional	(1)
			•	

LUBRICATION

- (Type 'J' Grease, No. 49-08-4220): Coat inside grooves of Bushing (inside gearcase) with grease. 36
- Lightly coat front washer surface of Anvil (38) with grease. Place a dab of grease in the Ball holes and in the hole in the back of the Anvil.

MILWAUKEE ELECTRIC TOOL CORPORATION

13135 W. Lisbon Road, Brookfield, WI 53005

No. 42-06-0301 3/8" SQUARE ANVIL ASSEMBLY (Original Design)




FIG. 1

IMPORTANT!


Hog Ring and O-Ring components of the 3/8" Square Anvil Assemblies for M12™ Impact Wrenches are unique and are <u>NOT INTERCHANGE-ABLE</u> between Anvil Assemblies


Original Anvil Assembly 42-06-0301 (Fig. 1) uses Hog Ring 44-90-1000 and O-Ring 34-40-0475

Service Replacement Anvil Assembly 42-06-0310 (Fig. 2), identified by an etched symbol on the front face of the anvil, use Hog Ring 44-90-1050 and O-Ring 34-40-1885

If you have any questions please call After-Sales Service-Technical Support 1.800.729.3878

No. 42-06-0310 3/8" SQUARE ANVIL ASSEMBLY (Service Replacement)





WIRING SPECIFICATIONS						
Wire No.	Wire Color	Origin or Gauge	Length	Terminals, Connectors and 1 or 2 End Wire Preparation		
1	Black	23-30-0090		Component of the motor assembly.		
2	Red	23-30-0090		Component of the motor assembly.		
3	White	23-66-1105		Component of the electronics module assembly.		
4	Black	23-66-1105		Component of the electronics module assembly.		
5	Black	23-66-1105		Component of the electronics module assembly.		
6	Red	23-66-1105		Component of the electronics module assembly.		
7	White	23-66-1105		Component of the electronics module assembly.		
8	Red	23-66-1105		Component of the electronics module assembly.		
9	Red	23-66-1105		Component of the electronics module assembly.		
10	Yellow	23-66-1105		Component of the electronics module assembly.		
11	Blue	23-66-1105		Component of the electronics module assembly.		
12	Black	23-66-1105		Component of the electronics module assembly.		
13	Sleeve	23-66-1105		Component of the electronics module assy. / Fuel gauge LED.		